

## DANGER

Never work under raised equipment unless additional supports are used under the lifted equipment.



After you have properly hooked the raised equipment to a mobile vehicle, lower the lifting mechanism of the Equipment-Agricultural Jack to its base and move the reversing latch into the up position.

## LOWERING A LOAD

## DANGER

Lowering the load can be dangerous. Keep your head clear of the path of the handle. During lowering, the weight of the load pushes UP against the Jack's handle. If your hands slip off the handle, or if the handle is horizontal when you move the reversing latch, it may move up very quickly. If your head is in the handle's travel path, it could strike you, causing serious injury or death.



### IMPORTANT:

The Jack must have a load on it (150 pounds or more) to lower step-by-step. Otherwise, the lifting mechanism will slide down to the base plate, "dropping" your load.

1. Before you move the reversing latch down, clip the handle in the upright position against the steel standard (bar).
2. Move the reversing latch to the DOWN position.
3. Grasp the handle firmly with both hands. Carefully pump the handle up and down to begin lowering the load.
4. The load will be lowered on each **UP** stroke of the handle. If the Jack binds, see instructions on page 13.

